


SPECIFICATION

NEXLEDS[®]
NEXLEDS LTD



- Wifi+Bluetooth
ENABLED
- APP
CONTROL
- RGB+CW
+16 Million colors
- APP
DIMMER
- CRI(Ra)
80+
- Wet
Location
- FCC



SMART LED RGBCW Strip

NX10RGBCW-3.6WM 18W


Specification

PRODUCT NAME :	Smart LED RGBCW Strip
MODEL NO. :	NX10RGBCW-3.6WM
SPECIFICATION :	DC12V,18W
WORKING TEMP :	-20-50(°C)
CRI(RA) :	>80
BODY COLOR :	White
LIGHT SOURCE :	SMD 5050 RGB,300 Chips
LIFE TIME :	30000 hrs
BEAM ANGLE :	120 degrees
PRODUCT SIZE :	5000*10mm, 5meter/Roll
CUTTING LENGTH:	50 mm
IP :	IP65
APPLICATION :	Home, Shop, Hotel
WARRANTY :	2 years
STANDARD :	FCC
COLOR TEMP :	RGBCW+16 Million colors
ENABLED :	Wifi+Bluetooth
DIMMABLE :	YES


Installation:




① Choose a dry, clean and smooth surface.
(Notice: Do not stick the led strip on the surface, such as knitted / wool fabrics, dust wall, rough plastic surface, frosted glass.)




② Strip off the protective film.
(Notice: Do not peel off the tape under the film.)




③ Stick the strip light and press over it about 10~15s.




④ For corner setup, bend the strip and reinforce via clips.
(Notice: Avoid bending on LED beads.)



⑤ Connect the arrow of controller to the arrow of LED Strip Lights.



⑥ Connect the controller to the DC wire.



⑦ Installation completed.
Use the IR remoteto turn on and operate the lights.

Warning

- ① Do not connect to the power supply before installation.
- ② Please spread out the light strip before connecting the power supply.

IR Remote Controller:

<p>For Full Color light strips only</p>	1.On/Off: Press to turn the light on/off.
	2.Adjust Brightness: Dim or brighten the light.
	3.Color Selecting: Press to change the color. R: Red, G: Green,B: Blue, W: White
	4.Colorful Mode: Press to change the colorful scene mode.
	5.Speed: For scene mode, press it to speed up or slow down the changing of lights; For music mode, press it to increase or decrease the sensitivity of the mic.
	6.Rainbow Mode: Press to cycle through Four rainbow scene modes.
	7.Music Mode: Press to cycle through Four music modes.

NOTICE:

- 1. Please pull out the transparent chip from the bottom of the IR remote to ensure that the battery is powered properly.
- 2. Make sure the IR remote aims at the controller within the sensing distance. The angle of the controller is 120° and the sensing distance is 3 meters. Please remotely control within the sensing range.